

---

## QUICK INSTALLATION GUIDE

---

MICRO REPEATER (LAN-WMBUS-uR-B)




### Recommended mounting instructions:

- Should be mounted on an interior wall
- Must be protected from water if mounted outside
- The UP text and symbol on the mounting bracket must point upwards
- The label on the device should be on the right side when mounted
- Mount the bracket with screws


### Step 1:

Find a suitable place to install the repeater.



### Step 2:

Turn the device upside down. Remove the mounting bracket by pushing the two plastic pieces, marked by red circles, inwards and then lifting the bracket up.




### Step 3a:

Locate the small, black, plastic jumper on the left side of the battery. Remove the jumper.

### Step 3b:

Place the jumper so it is connected to the two pins on the board. When the jumper connects the two pins, the device is automatically powered on and the red LED will start to flash.

The startup sequence is successful when the flashing stops.



### Step 4a:

Fasten the mounting bracket using the recommended mounting instructions, with the text UP pointing upwards.

Use two screws in the two holes filled with red in the picture.

### Step 4b:

Mount the device on the mounting bracket. Make sure the label at the side of the device is on the right side.

The installation is now complete!